



# Electrolux

## ultraone™

### CONSUMABLES & ACCESSORIES

 [www.electrolux.com/shop](http://www.electrolux.com/shop)



**Silent Parketto**  
Ref: ZE115  
Part nr: 9001677922



**Turbo Brush**  
Ref: ZE119  
Part nr: 9001678003



**Delicate Care**  
Ref: KIT11  
Part nr: 9001679597



**Clean & Tidy**  
Ref: KIT12  
Part nr: 9001679605



**Animal Care**  
Ref: KIT13  
Part nr: 9001679613



**Performance Kit**  
Ref: SRK15  
Part nr: 9001688903



**s-bag® Ultra Long Performance**  
Ref: E210S  
Part nr: 9001684613  
**s-bag® Anti-allergy**  
Ref: E206S  
Part nr: 9001684605  
**s-bag® Anti-odour**  
Ref: E203S  
Part nr: 9001684597  
**s-bag® Classic Long Performance**  
Ref: E201S  
Part nr: 9001684589



**Hygiene Washable**  
Ref: EFH12W  
Part nr: 9001951194  
**Allergy Plus Washable**  
Ref: EFS1W  
Part nr: 9001677682



**Crispy Bamboo**  
Ref: ESBA  
Part nr: 9001677773  
**Brown Sugar & Fig**  
Ref: ESFI  
Part nr: 9001677781  
**Tropical Breeze**  
Ref: ESCO  
Part nr: 9001677799  
**Citrus Burst**  
Ref: ESMA  
Part nr: 9001677807  
**Evening Rose**  
Ref: ESRO  
Part nr: 9001677765

 [supportemea.electrolux.com](mailto:supportemea.electrolux.com)

 [www.electrolux.com](http://www.electrolux.com)

B11450202

