



Delicate glasses are in good hands


Glasses need a little extra tender loving care, especially when getting washed. Good thing the upper basket in the 700 GlassCare dishwasher has SoftGrips that securely yet gently hold your glasses. While SoftSpikes make sure they don't get scratched, or worse break.

Product Benefits & Features



Delicate glasses protected with SoftGrips and SoftSpikes

With SoftGrips and SoftSpikes you no longer need to spend time handwashing delicate glasses. The soft material gently holds glasses securely in place and protects them from cracks and breakage.



SatelliteClean®. Complete cleaning. Without using extra water

Dishes come out spotless with SatelliteClean®—it performs up to 3x better than the standard dishwasher. Thanks to the double-rotating arm that continuously changes the angle of the spray, even bulky items are deeply cleaned.



Removes more than 99,999% of bacteria and viruses*

The ExtraHygiene function gives you maximum cleaning performance with hygienic care. With the ExtraHygiene function, the final rinse phase heats up to 69°C and keeps the temperature high for minimum 10 minutes to sanitize your dishes, removing more than 99,999% of bacteria and

*Tested for Micrococcus luteus and MS2 bacteriophage in external test performed by Swissatest Testmaterialien AG in 2021 (Test Report No. 20212029).

More Visibility, More Efficient Loading

The internal light gives you a direct view of the dishwasher's interior. You can efficiently find the best spots for cleaning each of your specialist cooking tools.



QuickLift - change the basket height even when fully loaded

Whether loading or removing dishes do it comfortably with the QuickLift basket. Even when the upper basket is fully loaded, the QuickLift system allows you to quickly raise and lower your rack to fit dishes and kitchen tools of different shapes and sizes.

- XXL tub
- Auto Off function
- Panel with symbols
- Touch control for programs and functions selection
- Panel with 3 digits display
- Internal light for optimal visibility in the dishwasher
- Drying system: AirDry Technology
- Cutlery basket
- Dual safety - Floating switch
- Indications for salt and rinse aid
- FlexiSpray Satellite spray arm
- Ceiling sprayarm
- Height adjustable upper basket, even when fully loaded
- Upper basket with 6 wine glass soft grips, 2 Foldable racks, 2 Foldable wires for glasses, 2 Soft Spikes, Foldable cup shelves, Plastic handle Electrolux
- Lower basket with 2 foldable tines, Plastic handle
- Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, Auto, Eco, Machine Care, Quick 30 Minutes, Rinse & Hold
- Delay Start

Product Specification

Installation	FSBU	Weighted average energy consumption / 100 cycles, kWh (E20)	84
Rated capacity psE20	13	Water consumption / cycle IE20	10.5
Energy efficiency class, legal (E20)	D	Hinges	Normal
Airborne acoustical noise emissions, dBA re 1 pW	42	Connected load, W	1550-2200
Door colour	White	Cord length, m	16
XXL-Tub	Yes	Outlet hose length, cm	180
Dimensions_Dishwasher_FSB_U_DK	820-880x600x570	Required fuse (A)	10
Number of programs	8	Inlet hose length, cm	180
Number of temperatures	4	Inlet hose type	Aqua control
Dimensions HxWxD in mm	818x597x576	Anti-flood device	Floating switch
Airborne acoustical noise emission class	B	Water supply	Cold or Hot
Depth open door	1180	Upper spray arm	Standard spray arm
Nordic_DW_CutleryType	Cutlery basket	Lower spray arm	Satellite spray arm
Nordic_DW_SoftGrips	6 SoftGrip holders	Options	ExtraHygiene, GlassCare, XtraPower
Nordic_DW_SoftSpikes	2 SoftSpikes holders	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 6cm)
Nordic_DW_GlassCare2G	No	Installation in height	None
Interior light	Yes	Indicator program	Display 3 digits
Nordic_DW_DoorFitKit	No	Installation type	Free_Standing
Cleaning performance index3 digitE20	1.121	Net weight, kg	43.03
Drying performance index 3 digitE20	1.061	Bar code	7333394108322
		Product Number Code	911 447 433

PSGBDW230DE00007

