



Provides up to 3x better coverage with no extra water

The 600 SatelliteClean® Dishwasher has an innovative spray arm that delivers 3x better spray coverage compared to the standard system. Guaranteeing corner-to-corner cleaning so that even closely stacked items are thoroughly washed.

Product Benefits & Features

SatelliteClean®. Complete cleaning. Without using extra water

Dishes come out spotless with SatelliteClean®—it performs up to 3x better than the standard dishwasher. Thanks to the double-rotating arm that continuously changes the angle of the spray, even bulky items are deeply cleaned.



All your cutlery, washed in one go with MaxiFlex

The MaxiFlex drawer is designed to fit cutlery and utensils of different shapes and sizes. Whether large or awkwardly shaped, the customisable dividers and deep drawer mean everything can be loaded with ease.

Sustainable dishwashing made easy

Sustainable choices made easy. Use the QuickSelect touchscreen slider to select your preferred cycle time and the Ecometer displays the most sustainable program to save energy and water through intuitive green bars.



Soft support for your delicate glasses

To minimise the risk of damage or breakages during the dishwashing process, SoftSpike rubber supports keep your delicate glasses standing safely upright.



Silent feedback, Beam on Floor

The Beam on Floor illuminated feedback system keeps your kitchen quiet. Instead of a loud beep that can be drowned out by background noise, our dishwasher clearly tells you its status by projecting a dot on the floor. Red when it's running, and green when it's complete.

- Auto Off function
- Touch control for programs and functions selection
- Drying system: AirDry Technology
- Water sensor detects the level of dirt and adjusts water consumption
- Dual safety - Floating switch
- Indications for salt and rinse aid
- FlexiSpray Satellite spray arm
- Ceiling sprayarm
- Height adjustable upper basket, even when fully loaded
- Upper basket with 2 Soft Spikes, Foldable cup shelves, Plastic handle
- Lower basket with 2 foldable tines, Plastic handle
- Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes, Rinse & Hold
- Delay Start

PSGBDW210DE0008

Technical drawing showing the front and side views of the unit with dimensions:

- Front View Dimensions:
 - Top width: 596
 - Top depth: 550
 - Left height: 820-900
 - Left depth: min. 550
 - Bottom left depth: 600
 - Right height: 818-898
 - Right depth: 650
- Side View Dimensions:
 - Top width: 1200
 - Top depth: 50
 - Left height: 150
 - Right height: max. 130
 - Bottom right depth: 645-776
- Bottom View Dimensions:
 - Left height: 820
 - Left depth: **900
 - Right height: 940
- Legend:
 - ** 40-175
 - ** 100-235
 - ** 160-295