

# **EEA47213L**





#### Natural drying with fresh air

Our 300 AirDry Dishwasher finishes each cycle with a breath of fresh air, performing 3x better than closed-door systems. The door opens automatically during the drying phase using fresh air to get plates and cutlery completely dry.

#### **Product Benefits & Features**



### 3x better drying with AirDry

The new AirDry technology uses natural airflow to finish drying, for up to 3x better performance compared to closed-door systems. The door opens 10 cm towards the end of the cycle, letting air circulate for superb drying results.

#### Sustainable dishwashing made easy

Sustainable choices made easy. Use the QuickSelect touchscreen slider to select your preferred cycle time and the Ecometer displays the most sustainable program to save energy and water through intuitive green bars.



## Silent feedback, Beam on Floor

The Beam on Floor illuminated feedback system keeps your kitchen quiet. Instead of a loud beep that can be drowned out by background noise, our dishwasher clearly tells you its status by projecting a dot on the floor. Red when it's running, and green when it's complete.



# QuickLift - change the basket height even when fully loaded

Whether loading or removing dishes do it comfortably with the QuickLift basket. Even when the upper basket is fully floaded, the QuickLift system allows you to quickly raise and lower your rack to fit dishes and kitchen tools of different shapes and sizes.

## Clean dishes, quickly

Save time with the quick wash program. Enjoy clean dishes in the quickest way

- Auto Off function
- Touch control for programs and functions selection
- Drying system: AirDry Technology
- Cutlery basket
- · Water sensor detects the level of dirt and adjusts water consumption
- Dual safety Floating switch
- · Indications for salt and rinse aid
- · Ceiling sprayarm
- · Height adjustable upper basket, even when fully loaded
- Door Fit Kit included
- Upper basket with Foldable cup shelves, Plastic handle
- Lower basket with 2 foldable tines, Plastic handle
- Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes, Rinse & Hold
- Delay Start



# **EEA47213L**

Product Specification			
Installation	FI	Weighted average energy consumption / 100 cycles, kWh (E20)	94
Rated capacity psE20	13	Water consumption / cycle IE20	9.9
Energy efficiency class, legal (E20)	Е	Hinges	Sliding
Airborne acoustical noise emissions, dBA re 1 pW	44	Connected load, W	1950
Door colour	None	Cord length, m	15
XXL-Tub	No	Outlet hose length, cm	150
Dimensions_Dishwasher_FSBU_DK	820-900x600x550	Required fuse (A)	10
Number of programs	8	Inlet hose length, cm	150
Number of temperatures	4	Inlet hose type	Aqua control
Dimensions HxWxD in mm	818x596x550	Anti-flood device	Floating switch
Airborne acoustical noise emission class	В	Water supply	Cold or Hot
Depth open door	1200	Upper spray arm	Standard spray arm
Nordic_DW_CutleryType	Cutlery basket	Lower spray arm	Standard
Nordic_DW_QuickSelect	Level 2	Options	GlassCare, XtraPower
Nordic_DW_GlassCare2G	No	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)
Beam on floor	Red&Green	Installation in height	None
Interior light	No	Nordic_DW_DoorPanelHeight	645-776
Nordic_DW_DoorFitKit	Yes	Nordic_DW_DoorPanelWeight	2-10
Cleaning performance index3 digitE20	1.121	Indicator program	LED
Drying performance index 3 digitE20	1.061	Installation type	Built_In
		Net weight, kg	37
		Bar code	7333394107523
		Product Number Code	911 536 670

