


Save up to half the time when you grill, roast or bake

The 600 CombiQuick® CombiOven combines hot air circulation with microwaving for delicious results up to twice as fast. 2-in-1 functionality means you can grill, roast or bake – or use it as a microwave to defrost or reheat.

Product Benefits & Features

Combine microwave and oven functions to cook up to twice as fast

Combined microwave and convection oven for delicious food in as little as half the time. The microwave function efficiently re-heats, cooks and defrosts your dish. The convection system's fan circulates hot air to evenly cook your dish.

EXPLORE LED Display with Touch buttons

The EXPLORE display allows you to effortlessly control the settings of your oven. With the LED display and 5-touch buttons, you can easily see the time, temperature and progress of your dish while easily accessing other functions and get your oven connected.

Automatic settings, consistent results with Assisted Cooking

Get intuitive access to the best settings for preparing many different dishes via the Assisted Cooking function. Choose whether to let the oven adjust automatically or fully control the time and temperature yourself.

Assistance, inspiration and control – everywhere – with the App

App-controlled functions at your fingertips. The Electrolux app improves your whole cooking experience. Use it to control the oven, get personalised assistance, learn new techniques, and more, no matter where you are.

Hot air for even cooking

Ensure your dishes are cooked all the way through with the Hot Air Fan. The clever convection system circulates hot air evenly inside your oven so that cooking is consistent across all levels. Everything is cooked from corner to corner, top to bottom.

- Oven with integrated microwave function
- Touch control
- Fast oven heat up function
- Electronic temperature regulation
- VarioGuide
- Automatic temperature proposal
- Automatic safety switch off oven function
- Residual heat indication
- FloodLight™
- Cooling fan
- Child Lock safety function for control panel
- Door lock
- Accessories included: 1 Cake tray grey enamel, 1 Wire shelf chromed

Product Specification

Main colour	Pure black
Cleaning main oven	Clean Enamel
Volume usable, l Main Oven	44
Electronic type	PINE
Dimensions HxWxD in mm	455x595x567
BI dimensions HxWxD in mm	450x560x550
Temperature range	30°C - 230°C
Microwave output power, W	1000
Grill element power, W	1900
Nordic_ov_Accessories_TopOven	1 Cake tray grey enamel/1 Wire shelf chromed/Wood screws
Cord length, m	2
Total electricity loading, W	3000
Plug Type	Schuko
Volt, V	220-240
Required fuse (A)	16
Product Number Code	944 005 347
Bar code	7333394144672