


Powerful cleaning with spacious, flexible baskets

The 800 series delivers the cleaning power to completely remove baked-on or dried food residues. Flexible, easy-gliding baskets have foldable rows, plus holders to secure glasses and Eco-program uses as little as 8.4 litres of water.

Product Benefits & Features
Double-rotating spray disk cleans from all directions


Complete removal of stubborn food-residues in only 90 min. Tested and verified*. A spray arm with two nozzles, one circular and one straight, efficiently delivers water from multiple angles. The result is sparkling dishes every time.

*Based on an independent test by third-party German institute using detergent tablets and 90 min cycle on casserole with lasagna residues

Versatile baskets with folding sections and unique glass holders


Smooth-gliding FlexiMax Plus baskets have three folding rows for flexible loading. Anti-slip rubber grips and spikes secure stemware and glasses, reducing the risk of collisions. Cutlery drawer has deep middle section for cooking tools.

1 cycle, 2 zones. Intense on pots and pans, gentle on glassware


Two cleaning zones in the same cycle, without changing water or energy use. Activate DualZone to get tailored cleaning, with more water pressure on pots and pans in the lower basket and reduced pressure on delicate items in the upper basket.

Effective, efficient cleaning using water only where needed


WaterSmart is a water system with spray arms that work individually, directing water where it's needed. The result is efficient cleaning with as low as 8.4 litres of water, when using the Eco program.

Just select cycle time. No need to choose between programmes


An easier way to use your dishwasher. QuickSelect Connect display shows how energy use changes, depending on the cycle length. Move the slider to choose time, and see the energy graph change. Loading, program, and maintenance tips in the app.

- LightOnFloor
- Interior light
- Touch control for programs and functions selection
- Delay Start
- Indications for salt and rinse aid
- AirDry
- WaterSmart
- Auto Off function
- Upper basket with 2 front folding tines for glasses with tine caps, 2 front folding tines for saucer with tine caps, 2 Soft Spikes, 6 wine glass soft grips, Foldable cup shelves, stainless steel handle ELUX
- Lower basket with Plastic handle, 2 front foldable tines with tine caps, 4 rear foldable tines with tine caps, Tall flat rack frame
- Options: DualZone, ExtraHygiene, GlassCare
- Dishwasher programmes: 120 Minutes, 60 Minutes, 90 Minutes, AUTOClean, ECO, MachineClean, QuickClean, QuickRinse

Product Specification

Installation	FI	Cleaning performance index3 digitE20	1.121
Rated capacity psE20	14	Drying performance index 3 digitE20	1.061
Energy efficiency class, legal (E20)	A	Weighted average energy consumption / 100 cycles, kWh (E20)	54
Airborne acoustical noise emissions, dBA re 1 pW	40	Water consumption / cycle IE20	8.4
Door colour	None	Hinges	Sliding up to 12kg
XXL-Tub	No	Connected load, W	1550-2200
Dimensions_Dishwasher_FSBU_DK	820-900x600x550	Cord length, m	1.6
Number of programs	8	Outlet hose length, cm	180
Number of temperatures	3	Required fuse (A)	10
Dimensions HxWxD in mm	815x596x550	Inlet hose length, cm	180
Airborne acoustical noise emission class	B	Inlet hose type	Aqua control
Depth open door	1235	Anti-flood device	Floating switch
Connectivity	Yes	Water supply	Cold or Hot
Nordic_DW_CutleryType	Cutlery drawer	Upper basket, Level 1, max	210
Nordic_DW_QuickSelect	Level 3	Upper basket, Level 2, max	180
Nordic_DW_SoftGrips	6 SoftGrip holders	Lower basket, Level 1, max	260
Nordic_DW_SoftSpikes	2 SoftSpikes holders	Lower basket, Level 2, max	290
Nordic_DW_GlassCare2G	No	Upper spray arm	Standard spray arm
Beam on floor	LightOnFloor	Lower spray arm	360Clean Pro
Interior light	Yes	Options	DualZone, ExtraHygiene, GlassCare
Nordic_DW_DoorFitKit	No	Options available only through the App	ExtraDry, ExtraQuiet, HalfLoad, PowerBoost, SprayZone
		Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)

