




Electrolux



Instruction Book

900 CORDLESS CLEANER
















*Actual product may differ from illustration.

The Product



LIBP216LI44-SA (6 cells),
DC 21.6V, 4400mAh



* Accessories may vary from model to model. | Les accessoires peuvent varier d'un modèle à l'autre. | Ausstattung und Zubehör kann je nach Modell variieren. | Accessoires kunnen per model verschillen. | Tillbehören kan variera mellan olika modeller. | Lisävarusteet voivat vaihdella malleittain. | Tilbehør kan variere fra model til model. | Tilbehør kan variere fra modell til modell. | Los accesorios pueden variar según el modelo. | Os acessórios podem variar de modelo para modelo. | Gli accessori possono variare da modello a modello. | Τα εξαρτήματα ίσως διαφέρουν από μοντέλο σε μοντέλο. | Lisad võivad mudelist mudelisse varieeruda. | Priedai kitiems modeliams gali skirtis. | Akcesoria mogą się różnić w zależności od modelu. | Piederumi katram modelim var atšķirties. | Příslušenství se může u jednotlivých modelů lišit. | Doplnky sa môžu líšiť v závislosti od modelu. | Dodaci se mogu razlikovati kod određenih modela. | Nastavki se lahko glede na model razlikujejo. | Принадлежности могут отличаться от модели к модели. | Ці компоненти можуть відрізнятися залежно від моделі. | Tartozékok típusonként eltérőek lehetnek. | Accesoriiile pot diferi de la model la model. | Принадлежностите може да се различават според различните модели. | Aksesuarlar, modelden modele farklılık gösterebilir. | رخآل ليدوم نم فلتخت دقت اقمرل. | Додаци могу да се разликују у зависности од модела усисивача. | อุปกรณ์เสริมอาจแตกต่างกัน ในแต่ละรุ่น. | 仅特定机型提供 | 약세사리는 모델마다 다를 수 있습니다. | Els accessoris poden canviar segons el model



For indoor use only.

Note: This instruction book should be read together with safety precaution booklet.








Carpet







Hard Floor

www.electrolux.com













Setup & Installation




Using the Emptying Station






Understanding the Display Panel




Accessory Usage




PowerProMop+ Nozzle: Usage & Care Instructions

























Handheld Unit Maintenance



Nozzle Care & Maintenance



Safety Guidelines



www.shop.electrolux.com



ESKW10

900 923 838
Performance Kit




ZE202

900 923 839
Extra Battery
4.4Ah/95Wh




ZE177

900 923 744
PowerProMop+ Nozzle




ZE155

900 923 379
PetPro+



ZE204

900 923 841
HardFloor Power




ZE158

900 923 440
Standard Pads




KIT23

900 923 383
Home and Car Kit




KIT22

900 923 354
Duster Kit




EPPCS2

900 923 726
Cleaning Station



E201S

900 168 458
S-bag® Classic Long Performance
for Emptying Station



E206S

900 168 460
S-bag® Hygiene Anti-Allergy
for Emptying Station



E203S

900 168 459
S-bag® Anti-Odour
for Emptying Station

*Accessories may vary by market.

